


# HANDSIGNALER FÖR MOBILKRAN




## 1. HISSA

Upplyft arm och pekfingeret uppåt.  
Cirkelrörelse med handen.




## 2. FIRA

Nedåtriktad arm och pekfingeret nedåt.  
Cirkelrörelse med handen.




## 3. TELESKOP IN

Sidorörelse inåt med båda händerna.  
Tummarna inåt.



## 4. SVÄNG VÄNSTER

Höger arm utsträckt.  
Handen öppen.



## 5. SVÄNG HÖGER

Vänster arm utsträckt.  
Handen öppen.



## 6. TELESKOP UT

Sidorörelse utåt med båda händerna.  
Tummarna utåt.



## 7. RES BOMMEN

Utsträckt arm.  
Tummen uppåt.



## 8. FÄLL BOMMEN


Utsträckt arm.  
Tummen nedåt.



## 9. STOPP


Utsträckt arm svängs  
i båge framåt och åt sidan.

# MOBILE CRANE HAND SIGNALS




## 1. HOIST

With forearm vertical, forefinger pointing up, move hand in small horizontal circles.




## 2. LOWER

With arm extended downward, forefinger pointing down, move hand in small horizontal circles




## 3. RETRACT BOOM

Both fists in front of body with thumbs pointing in toward each other.




## 4. SWING LEFT

Arm extended, point with finger in direction of swing of boom.



## 5. SWING RIGHT

Arm extended, point with finger in direction of swing of boom.




## 6. EXTEND BOOM

Both fists in front of body with thumbs pointing outward.



## 7. RAISE BOOM

Arm extended, fingers closed, thumb pointing upward.



## 8. LOWER BOOM

Arm extended, fingers closed, thumb pointing downward.



## 9. STOP

Arm extended, palm down, move arm back and forth horizontally.